

GIVK Guscio di coibentazione valvole (fig 1)

Il guscio di coibentazione valvole **GIVK** evita il formarsi della condensa nel corpo valvola.
 Gli attacchi idraulici sono previsti sia a destra sia a sinistra.
 Installare la **GIVK** come rappresentato nelle figure 2 e 3.

GIVK Valve stem insulation shell (fig 1)

The **GIVK** valve stem insulation shell it avoids forming itself of condensates in to valve.
 The hydraulic attacks are previewed are to right are on the left.
 Install the **GIVK** as indicated in the figures 2 and 3.

COME ORDINARE

Codice	Sigla	Descrizione	Attacchi idraulici
EYGIVK1SR	GIVK1SR	Guscio isolante per valvola VK1S	Destra
EYGIVK1SL	GIVK1SL	Guscio isolante per valvola VK1S	Sinistra
EYGIVK8SR	GIVK8SR	Guscio isolante per valvola VK8S	Destra
EYGIVK8SL	GIVK8SL	Guscio isolante per valvola VK8S	Sinistra
EYGIVK10SR	GIVK10SR	Guscio isolante per valvola VK10S	Destra
EYGIVK10SL	GIVK10SL	Guscio isolante per valvola VK10S	Sinistra

HOW TO ORDER

Code	Model	Description	Water connection
EYGIVK1SR	GIVK1SR	VK1S Insulating valve shell	Right
EYGIVK1SL	GIVK1SL	VK1S Insulating valve shell	Left
EYGIVK8SR	GIVK8SR	VK8S Insulating valve shell	Right
EYGIVK8SL	GIVK8SL	VK8S Insulating valve shell	Left
EYGIVK10SR	GIVK10SR	VK10S Insulating valve shell	Right
EYGIVK10SL	GIVK10SL	VK10S Insulating valve shell	Left



40010 Bentivoglio (BO)
 Via Romagnoli, 12/a
 Tel. 051/8908111
 Fax 051/8908122
 www.galletti.it